32" LCD Television FLM-3201

Operating Manual



20050502



Table of Contents

Important Information	1
Important Safety Precautions	2
Preparations	5
Using the Remote Control	5
Batteries for the Remote Control	5
Power Connection	5
Antenna Connection	6
Identification of Controls	7
Main Unit	7
Remote Control	9
Connections	11
Cautions Before Connecting	11
Connect a VCR	11
Connect a Camcorder	12
Connect a DVD player (or Set-Top Box)	13
Connect a DTV receiver	14
Connect a PC	15
Connect a VCR for Recording	16
Turning the Unit On and Off	17
Turning the Unit On and Off	17
Viewing the Menus and Displays	
Memorizing the Channels	
Selecting the Signal Source	18
Storing Channels in Memory Automatically	18
Adding and Erasing Channels	
Basic Operations	20
Changing Channels	20
Adjusting the Volume	20
Selecting Input Source Signal	
Selecting a Menu Language	
Setting Picture	
Customizing the Picture	
Using the Preset Picture Mode	22
Setting System	
Setting System In TV Mode	
Adjusting Screen Aspect	23
Reducing Picture Noise	23
VCR mode	
Loading Default Values	
Setting System In VGA Mode	
Changing the Position of Image	
Adjusting Clock and Phase	
Adjusting the Picture Automatically	
Adjusting Screen Aspect	
Displaying Resolution Information	
Loading Default Values	

Table of Contents (continued)

Setting System In YPbPr Mode	26
Adjusting Phase	
Adjusting Screen Aspect	
Reducing Picture Noise	
Loading Default Values	26
Setting System In DVI Mode	27
Adjusting Screen Aspect	
Displaying Resolution Information	
Setting Sound	
Customizing the Sound	
Using the Preset Sound Mode	
Setting SRS effect	
Adjusting On-Screen Display	
Adjusting OSD Position	
Adjusting OSD Transparence	
Zooming OSD Menu	
Setting OSD Off Time	
Loading default values	
TVPC Operations	
Viewing the TVPC	
Selecting the Signal Source for the TVPC Frame	
Changing Channels for the TVPC Frame	
Changing the Position of the TVPC Frame	
Adjusting the Size of TVPC Frame	
Viewing Picture-by-Picture	
Using Hotkeys	
Setting Sleep Timer	
Setting Audio Mode	
To pause Picture	
Viewing Closed Captions	
Turning Closed Caption On or Off	
Setting Closed Caption	
Setting CC When Mute	
Adjusting Child Lock Settings	
Child Lock	
Turning Child Lock On or Off	
Changing the Password	
Adjusting the Movie Rating	
Adjusting the TV Rating	
Adjusting Canadian English Rating	
Adjusting Canadian French Rating	
Troubleshooting	
Care and Maintenance	
Specification	
Programming the Universal Pemete Central	

Important Information

WARNING:

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.



CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION-To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

"Note to CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the National Electrical Code that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical."

This product utilizes tin-lead solder, and fluorescent lamp containing a small amount of mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eia.org

FCC STATEMENT

FCC Notice

LCD TV: A CLASS B digital device

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC CAUTION:

Pursuant to 47CFR, Part 15.21 of the FCC rules, any changes or modifications to this monitor not expressly approved by the manufacturer could cause harmful interference and would void the user's authority to operate this device.

WARNING: This is a CLASS B product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures to counter interference.


Important Safety Precautions

Electrical energy can perform many useful functions, but it can also cause personal injuries and property damage if improperly handled. This product has been engineered and manufactured with the highest priority on safety. But IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARD. In order to prevent potential danger, please observe the following instructions when installing, operating and cleaning the product. To ensure your safety and prolong the service life of your LCD TV product, please read the following precautions carefully before using the product.


- 1. Read these instructions---All operating instructions must be read and understood before the product is operated.
- **2. Keep these instructions---** These safety and operating instructions must be kept in a safe place for future reference.
- 3. Heed all warnings---All warnings on the product and in the instructions must be observed closely.
- **4. Follow all instructions**—All operating instructions must be followed.
- **5. Do not use this apparatus near water**---for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like. Do not use immediately after moving from a low temperature to high temperature environment, as this causes condensation, which may result in fire, electric shock, or other hazards.



6. Clean only with dry cloth---Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.



7. Ventilation---Do not block any ventilation openings. Install in accordance with the manufacturer instructions. The vents and other openings in the cabinet are designed for ventilation. Do not cover or block these vents and openings since insufficient ventilation can cause overheating and/or shorten the life of the product. Do not place the product on a bed, sofa, rug or other similar surface, since they can block ventilation openings. This product is not designed for built-in installation; do not place the product in an enclosed place such as a bookcase or rack, unless proper ventilation is provided or the manufacturer's instructions are followed.



8.Heat sources---Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.



- **9.Grounding or Polarization**---Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- **10.Power cord protection---**Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- **11.Attachments**—Only use attachments/accessories specified by the manufacturer. Do not use attachments not recommended by the manufacturer. Use of improper attachments can result in accidents.

Important Safety Precautions (continued)


12. Stand---Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. Do not place the product on an unstable trolley, stand, tripod or table. Placing the product on an unstable base can cause the product to fall, resulting inserious personal injuries as well as damage to the product. When mounting the product on a wall, be sure to follow the manufacturer's instructions. Use only the mounting hardware recommended by the manufacturer.



13. Move Carefully---When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. Sudden stops, excessive force and uneven floor surfaces can cause the product to fall from the trolley.



14. Lightning---Unplug this apparatus during lightning storms or when unused for long periods of time. For added protection for this television equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to the equipment due to lightning and power-line surges.



- **15. Servicing---**Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- **16. Replacement parts**—In case the product needs replacement parts, make sure that the service person uses replacement parts specified by the manufacturer, or those with the same characteristics and performance as the original parts. Use of unauthorized parts can result in fire, electric shock and/or other danger.
- **17.Overloading**---Do not overload wall outlets, extension cords, or convenience receptacles on other equipment as this can result in a risk of fire or electric shock.
- **18.Entering of objects and liquids---**Never insert an object into the product through vents or openings. High voltage flows in the product, and inserting an object can cause electric shock and/or short internal parts. For the same reason, do not spill water or liquid on the product.
- **19.Damage requiring service--**-If any of the following conditions occurs, unplug the power cord from the AC outlet, and request a qualified service person to perform repairs.
- a. When the power cord or plug is damaged.
- b. When a liquid is spilled on the product or when objects have fallen into the product.
- c. When the product has been exposed to rain or water.
- d. When the product does not operate properly as described in the operating instructions. Do not touch the controls other than those described in the operating instructions. Improper adjustment of controls not described in the instructions can cause damage, which often requires extensive adjustment work by a qualified technician.
- e. If the product has been dropped or the cabinet has been damaged in any way.
- f. When the product displays an abnormal condition or exhibits a distinct change in performance. Any noticeable abnormality in the product indicates that the product needs servicing.
- **20.Safety checks---**Upon completion of service or repair work, request the service technician to perform safety checks to ensure that the product is in proper operating condition.
- **21.Wall or ceiling mounting**—When mounting the product on a wall or ceiling, be sure to install the product according to the method recommended by the manufacturer. This is a safety precaution.


Important Safety Precautions (continued)

- **22. Power source**—This product is intended to be supplied by a listed power supply indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power line surges. When the unit has to be used with another power supply voltage, the power cable must be changed. Consult your product dealer. The socket outlet should be installed near the equipment and easily accessible. Use only the power cord designated by our dealer to ensure safety and EMC. When connecting other products such as VCRs and personal computers, you should turn off the power of the unit for protection against electric shock.
- **23.Panel protection**—The LCD panel used in this product is made of glass. Therefore, it can break when the product is dropped or impacted upon by other objects. Be careful not to be injured by broken glass pieces in case the LCD panel breaks.




- **24.Pixel defect**—The LCD panel is a very high technology product, giving you finely detailed pictures. Occasionally, a few non-active pixels may appear on the screen as a fixed point of blue, green or red. Please note that this does not affect the performance of your product.
- If an outside antenna is connected to the television equipment, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



NEC—NATIONAL ELECTRICAL CODE

■ An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can collide with such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits, as contact with them might be fatal.



Preparations

Using the Remote Control

■ Use the remote control by pointing it towards the remote sensor window of the set. Objects between the remote control and sensor window may prevent proper operation.

Note: This illustration is for reference only. The remote sensor may be in different locations on different models.


Cautions regarding use of remote control

- Do not expose the remote control to shock. In addition, do not expose the remote control to liquids, and do not place in an area with high humidity.
- Do not install or place the remote control under direct sunlight. The heat may cause deformation of the unit.
- The remote control may not work properly if the remote sensor window of the main unit is under direct sunlight or strong lighting. In such a case, change the angle of the lighting or LCD TV set, or operate the remote control closer to the remote sensor window.


Batteries for the Remote Control

If the remote control fails to operate the LCD TV functions, replace the batteries in the remote control.


1 Open the battery cover.



- 2 Insert two size-AA batteries.
 - (Place the batteries with their terminals corresponding to the (+) and (–) indications in the battery compartment.)



3 Replace the cover.




Precaution on battery use

Improper use of batteries can result in a leakage of chemicals and/or explosion. Be sure to follow the instructions below.

- Place batteries with their terminals corresponding to the (+) and (–) indications.
- Different types of batteries have different characteristics. Do not mix batteries of different types.
- Do not mix old and new batteries. Mixing old and new batteries can shorten the life of new batteries and/or cause old batteries to leak chemicals.
- Remove batteries as soon as they are non-operable. Chemicals that leak from batteries can cause skin irritation. If chemical leakage is found, wipe with a cloth.
- The batteries supplied with the product may have a shorter life expectancy due to storage conditions.
- If the remote control is not used for an extended period of time, remove the batteries from the remote control.





- 1. Connecting the female plug to the AC socket on the unit.
- 2. Connecting the male plug to the wall outlet as illustrated.

Note.

- This illustration is for reference only. The AC plug may be different on different models.
- This product should be operated only from the type of power source indicated on the marking label.
- Always unplug the AC cord from power outlet when not using for a long period of time.


Antenna Connection

CABLE TV (CATV) CONNECTION

A 75-ohm coaxial cable connector is built into the set for easy hookup. When connecting the 75-ohm coaxial cable to the set, screw the 75ohm cable to the ANT. Terminal.

Some cable TV companies offer "premium pay channels". Since the signals of these premium pay channels are scrambled, a cable TV converter/descrambler is generally provided to the subscriber by the cable TV company.

This converter/descrambler is necessary for normal viewing of the scrambled channels. For more specific instructions on installing cable TV, consult your cable TV company. One possible method of utilizing the converter/descrambler provided by your cable TV company is explained below. Please note: An RF switch provided with two inputs (A and B) is required (not supplied).



"A" position on the RF switch (not supplied): You can view all unscrambled channels by using the TV's channel keys.

"B" position on the RF switch (not supplied): You can view the scrambled channels via the converter/descrambler by using the converter's channel kevs.

Note:


Consult your Dealer or Service Center for the type of splitter, RF switch or combiner that might be required.

ANTENNAS

The antenna requirements for good color television reception are more important than those for black & white television reception. For this reason, a good quality outdoor antenna is strongly recommended.

The following is a brief explanation of the type of connections that are provided with the various antenna systems.

- 1. A 75-ohm system is generally a round cable with F-type connector that can easily be attached to a terminal without tools (not supplied).
- 2. A 300-ohm system is a flat "twin-lead" cable that can be attached to a 75-ohm terminal through a 300-75-ohm adapter (not supplied).



300/75-ohm


VHF/UHF Antenna

A. Combination


OUTDOOR ANTENNA CONNECTION

Use one of the following two diagrams if you connect an outdoor antenna.

Connect the outdoor antenna cable lead-in to the ANT, terminal on the rear of the



Identification of Controls



1. POWER 也

Press this button to turn the unit ON from STANDBY mode. Press it again to turn the set back to STANDBY.

2. MENU

Press this button to access the Menu main page.

3. SOURCE

To access signal source select menu.

4. VOL+/-

Press the **VOL+** or **VOL-** button to directly increase or decrease the sound volume level; In OSD Menu, press these buttons to adjust the value or setting of each item.

5 CH+/-


Press these two buttons to directly change the TV channel; In OSD Menu, press these buttons to choose the OSD items.

Note:


Functions of **VOL+/-**, **CH+/-**, **MENU**, **SOURCE** and **POWER** \circlearrowleft are also provided to the remote control. This operation manual provides a description based on operating functions with the remote control.

Main Unit

Removing or installing the Back Cover



After all connections are made, aim the Insertion tabs toward the Locating grooves, then carefully push the Cover until it locks in place with a click.



- 1. AV outputs (Video, Audio L/mono, R)
 - Connect to the VCR input jacks to record programs.
- 2. AV2 inputs (Video, Audio L/mono, R)

Receive video/audio signals from external sources such as VCR or DVD player.

- 3. AV1 inputs (Video, Audio L/mono, R) / S-Video input
 - Receive video/audio signals from external sources such as VCR or DVD player.

Receive a S-Video signal from external source such as VCR or DVD player.

- 4. Antenna input
 - Allows you to connect cable or outdoor antenna.
- 5. D-sub (VGA) input /Audio in

Connect to the VGA/audio outputs on your PC.


- 6. DVI input /Audio in
 - Connect to the DVI/audio outputs on your DTV receiver.
- 7. HDTV inputs (Y, Pb, Pr, Audio L, R)

Connect to the audio and component output jacks of a DVD player or Set-Top Box.

Note:

The AV output terminals output audio/video signal inputted from Antenna input or AV inputs.

Remote Control



1. POWER 也

Turn the unit on or off

2.0~9 number buttons

Direct channel select

3. ENTER button

Channel enter button

4. INPUT

To access source select menu

5. LAST

To quickly jump between current channel and last selected channel.

6. VOL+/-

Used to adjust volume.

7. CH+/-

Used to switch channels.

8. MUTE

Sound mute

9. MENU

To access the Menu main page or exit menu operation

10. Menu navigation button: ▲ ▼ ◀ ▶

In Menu operation, use ▲ / ▼ to select menu item;

Use
√ ▶ to adjust selected item;

OK button

To confirm, enter submenu or toggle between the settings of the selected menu item.


11. EXIT

Used to exit the current menu and return to upper level menu.

Note:

In menu operation, CH+/- and VOL+/- button also can be used to navigate in menus.

Remote Control



12. ASPECT

To select screen aspect ratio

13. DISPLAY

To display channel status or signal information

14. STEREO

To select STEREO, SAP or MONO

15. SRS

To turn on or off the SRS sound effect *

16. PIP

To activate picture-by-picture

17. SIZE

To adjust TVPC frame size

18. CAPTION

To select CCD on/off and CCD channel

19. SLEEP

To set Sleep timer

20. PICTURE MODE

Picture mode select

21. SOUND MODE

Sound mode select

22. PIP INPUT

To select signal source for TVPC frame

23. TV/PC

To activate TVPC function

Note:

The TVPC function means you may view a TV program from a mini window while the main window is displaying a PC screen.


* The SRS symbo is a trademark of SRS Labs,Inc. SRS technology is incorporated under license from SRS Labs, Inc.

Connections

Cautions Before Connecting

- Carefully check the terminals for position and type before making any connections.
- The illustration of the external equipment may be different depending on your model.
- Loose connectors can result in image or color problems. Make sure that all connectors are securely inserted into their terminals.

 Refer to the operating manual of the external device as well.
- When connecting an external device, turn the power off on the panel to avoid any issues.



How to connect:


Connect the Audio/Video cables between the Audio (L/R)/Video jacks on the unit and VCR.

Note:

For better video, you can use the S-video terminal if your source supports it.

To play VCR

- 1. Turn on your LCD TV, press INPUT button on the remote control.
- 2. Press ▲ or ▼ to select *Video1*(AV1 IN) and press **OK** to confirm.
- 3. Turn on your VCR , insert a videotape and press the Play button.



Connect a Camcorder AUDIO R AUDIO L AV OUT VIDEO AUDIO R Audio AUDIO L/MONO AV2 INPUT VIDEO cable AUDIO R AUDIO L/MONO AV1 INPUT/ S-VIDEO IN Video VIDEO cable S-VIDEO ANTENNA INPUT OUT IN W White (AUDIO L) ® Red (AUDIO R)

How to connect:

Connect the Audio/Video cables between the Audio (L/R)/Video jacks on the unit and camcorder.

To playback Camcorder


- 1. Turn on your LCD TV , press INPUT button on the remote control.
- 2. Press ▲ or ▼ to select Video2 and press OK to confirm.
- 3. Turn on your camcorder and set it to output mode. (For details, refer to your camcorder owner's manual.)
- 4. Insert the tape into the camcorder and press Play button.

Note:

The operations of the camcorder may be different and is dependent on your model. Please read the owner's manual of your camcorder to confirm operation.



Connect a DVD player (or Set-Top Box)




How to connect a DVD Player (or Set-Top Box) using Component Video Connections:

Connect the Video cable between the Y, Pb, Pr input jacks on the unit and Y, Pb, Pr output jacks on the DVD player (or Set-Top Box). Connect the Audio cable between the AUDIO input jacks on the unit and AUDIO output jacks on the DVD player (or Set-Top Box).


To play DVD or Set-Top Box

- 1. Turn on your LCD TV, press INPUT button on the remote control.
- 2. Press ▲ or ▼ to select YPbPr.
- 3. Press OK to confirm.
- 3. Turn on your DVD player (or Set-Top Box).



Note:

The Y, Pb, Pr outputs on your DVD player are sometimes labeled Y, Cb, Cr or Y, U, V. If so, connect the cables to like colors.




How to connect:


- 1. Connect the cable or antenna to the antenna input jack on the DTV receiver.
- 2. Connect the DVI cable between the DVI input interface on the unit and DVI output interface on the DTV receiver .
- 3. Connect the Audio cable between the AUDIO input jack on the unit and AUDIO output jacks on the DTV receiver.

To Watch DTV

- 1. Turn on your LCD TV , press INPUT button on the remote control.
- 2. Press ▲ or ▼ to select DVI.
- 3. Press **OK** to confirm.
- 4. Turn on your DTV receiver.



Connect a PC




How to connect:

Connect a VGA cable between the VGA jack on the PC and the VGA input jack on the unit.

Connect an Audio cable between the AUDIO output on the PC and AUDIO input jack on the unit.

To Watch the PC screen

- 1. Turn on your LCD TV , press INPUT button on the remote control.
- 2. Press ▲ or ▼ to select VGA.
- 3. Press **OK** to confirm.
- 4. Turn on your PC and check for PC system requirements.
- 5. Adjust the screen resolution and settings on your computer to the preferred settings.



Connect a VCR for Recording AUDIO L @ 43111 VIDEO Audio AUDIO R 3 AUDIO L/MONO AV2 INPUT cable VIDEO Video AUDIO R 8 cable AV1 INPUT/ S-VIDEO IN AUDIO L/MONO VIDEO S-VIDEO ANTENNA INPUT ANT OUT S-VIDEO White (AUDIO L) ® Red (AUDIO R) Rear of the VCR VCR for recording

How to connect:

Connect the Audio/Video cables between the Audio (L/R)/Video jacks on the unit and VCR.

To record program

- 1. Turn on your LCD TV, select a program you wish to record.
- 2. Turn on your VCR, insert a videotape for recording.
- 3. Press the Record button to begin recording.

Note:

The AV output terminals output the audio/video signal from the Antenna input or AV inputs.

Turning the Unit On and Off

Turning the Unit On and Off

Turning On

Insert the power cord into the wall outlet.

Press the **Power** \circlearrowleft button on the remote control.

The unit will be turned on and you will be ready to use it's features.

Turning Off

With the power on, press the **Power** button on the remote control to turn off.

Note:


You can also use the **Power** Ubutton on the control panel on the main unit.

Viewing the Menus and Displays

Your LCD TV has a simple, easy-to-use menu system that appears on the screen. This system makes it convenient and fast to use features on the unit. The unit also lets you display the status of many of your LCD TV features.

Viewing the Menus

1 With the power on, press the **MENU** button on the remote control. The main menu appears on the screen. The picture menu is selected.



2 Use the ▲ or ▼ to select menu item. Use ◀ or ▶ to adjust value of item. Use **OK** to confirm, enter submenu or toggle the settings of the selected menu item. you can press the **MENU** button repeatedly to exit the menu operations.

Note:

To clearly introduce the menu operations, this operation manual provides a description based on operation with the remote control.

Displaying Status Information

Press the **DISPLAY** button on the remote control, the unit will display current status information such as channel number, audio mode or signal source, etc.


Memorizing the Channels

Your LCD TV can memorize and store all the available channels for both antenna and cable channels. After the available channels are memorized, use CH+/- to scan the channels.

Selecting the Signal Source

Before your LCD TV can memorize the available channels, you must specify the type of signal source that is connected to the unit. (i.e., an antenna or cable system)


- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **CH** item.




The TV/Cable menu item will be highlighted automatically.

4 Press **OK** to toggle between **TV** or **Cable**.


If you are connected to an antenna, please select TV. If you connect cable, please select cable.






Storing Channels in Memory Automatically

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **CH** item.
- 3 Press **OK** to access the submenu.
- Press OK to store channels in memory automatically.
 The unit will begin memorizing all the available channels. During the process of the Auto Search, you can press MENU to exit.






Memorizing the Channels (continued)

Adding and Erasing Channels

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select CH item.
- 3 Press OK to access the submenu.
- 5 Press ◀ or ▶ to select a channel number you want to add or erase.
 You can also use number buttons to select a desired channel number directly.
- 7 Press **OK** to toggle between **Add** or **Erase**.

When the item is set to erase, the selected channel will be erased. When the item is set to add, the selected channel will be added.





Changing Channels

Using the Channel Buttons (CH+ or CH-)

Press the CH+ or CH- to change channels.

When you press the **CH+** or **CH-**, the unit changes channels in sequence. You will see all the channels that the unit has memorized. You will not see channels that were erased.

Direct Accessing Channels

Press the number buttons to go directly to a channel.

To select a one-digit channel: press the **0-9 number buttons**, followed by **ENTER** button or wait for some seconds, and the unit automatically goes to the selected channel.

To select a two-digit channel: in **TV** mode, press the **0-9 number buttons** to directly go to the selected channel; while in **Cable** mode, press the **0-9 number buttons**, followed by **ENTER** button or wait for a few seconds, and the unit goes to the selected channel.

To select a three-digit channel: press the **0-9 number buttons** to input the channel number, then the unit goes to the selected channel.

Note:

When you use the number buttons, you can directly select channels that were erased.

Using the LAST button

Press this button to switch between the current channel and the last viewed channel.

Adjusting the Volume

Using the volume buttons (VOL+ and VOL-)

Press the VOL + or VOL - to increase or decrease the volume.

Using the Mute

Using the MUTE button

At any time, you can temporarily cut off the sound using the MUTE button.

- 1 Press the **MUTE** button and the sound cuts off.
- 2 To turn mute off, press the **MUTE** button again.

Basic Operations (continued)

Selecting Input Source Signal

- Press the INPUT button to access Source Select menu.
- 2 Press ▲ or ▼ to select a desired input source.
- 3 Press **OK** to confirm and the unit displays signal from the selected input source.

Source Select VGA DVI RF Video1 Video2 SVideo YPbPr

VGA-----Select signal from VGA (15-pin D-sub) interface.

DVI -----Select signal from DVI interface.

RF -----Select TV signal.

Video1-----Select signal from AV1 IN terminals.


Video2-----Select signal from AV2 IN terminals.

SVideo-----Select signal from S-video terminal.

YPbPr -----Select signal from YPbPr terminal.

Selecting a Menu Language


- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **OSD** item.
- 3 Press OK to access the submenu.
 The Language item will be highlighted automatically.
- 4 Press **OK** to toggle between **English**, **French** and **Spanish**.
- 5 Press MENU to exit.



Customizing the Picture

- 1 Press **MENU** to display the menu main page.

 The picture menu page will be displayed automatically.
- 2 Press **OK** to access the **Picture** submenu.
- 3 Press ▲ or ▼ to select the item you wish to change.
- 4 Press ◀ or ▶ to adjust the value of the item.
- 5 Press MENU to exit.



In TV/Video mode

Option	Function	Operation	Range
Color	Adjusts color saturation.): deeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeperdeeper<td>0~100</td>	0~100
Brightness	Adjusts screen brightness for easier viewing of dark picture such as night scenes and black hair.	▶ : lighter ∢ :darker	0~100
Contrast	Adjusts image contrast.	 : stronger : weaker	0~100
Sharpness	Adjusts image sharpness and displays a sharp image.		0~100
Tint	Adjusts tint for image.	 : greenish : purplish	0~100

In VGA/DVI mode

Option	Function	Operation	Range
Brightness	Adjusts screen brightness for easier viewing of dark picture such as night scenes and black hair.		0~100
Contrast	Adjusts image contrast.	stronger weaker weaker	0~100
Sharpness	Adjusts image sharpness and displays a sharp image.		0~100
Color Temp	Adjusts preset color temperature.	Use OK to toggle	6500K 9300K 12000K

Using the Preset Picture Mode

Use the **PICTURE MODE** button to quickly select picture mode.

There are three preset picture modes (**Bright, Soft** and **Nature**) and one user-set picture mode

(User). Each preset mode has its own picture settings.

Bright: Select for a bright picture.

Soft: Select for a finely detailed picture. **Nature**: Select for a normal picture.

Adjusted settings are stored in User mode.

Bright

Setting System In TV Mode

Adjusting Screen Aspect

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **System** item.
- 3 Press **OK** to access the submenu.

The Aspect Ratio item will be highlighted automatically.

4 Press **OK** repeatedly to select a desired aspect ratio.

You can select the image aspect ratio between 4:3, 16:9, Panorama and Zoom.

4:3 — For 4:3 signal format. This mode displays a 4:3 picture at its standard 4:3 size without any stretching.

16:9 — For 16:9 signal format. This mode displays 16:9 aspect ratio picture.

Panorama — In this mode the picture is progressively stretched toward each side of the screen.

Zoom — For 4:3 letterbox signal format. This mode stretches the picture horizontally and crops the top and bottom black bars of the picture.



You may quickly select the screen aspect by using the ASPECT button on the remote control.

Reducing Picture Noise

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select System item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select N/R item.
- 5 Press OK to select Off, Auto, Strong, Middle or Weak.

Sometimes a noisy picture may appear on the screen because of poor signal. This function helps to enhance the picture quality by reducing the noise.

MAIN MENU ♣ Picture ♣ Picture Aspect Ratio N/R VCR mode Defauit ■ OSD ■ TVPC ♠ Setup Auto

VCR mode

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select System item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select VCR mode item.
- 5 Press OK to select On or Off.


When you are watching VCR program type or receiving weak signal, please set the "VCR mode" item to "On". It helps to obtain a better synchronization and improve the stability of the picture.

MAIN MENU ♣ Picture ♣ Sound Aspect Ratio N/R VCR mode Default ■ OSD ■ TVPC ○ Setup On

Loading Default Values

You may guickly load default values by using the **Default** item.





Setting System In VGA Mode

Changing the Position of Image

The unit allows you to adjust the position of the screen if it is not well-aligned.

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select System item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ to select H position or V position item.
- 5 Press ✓ or ➤ to adjust the value of the item until the screen is well-aligned.

Adjusting Clock and Phase

- 1 Press MENU to display the menu main page.
- Press ▲ or ▼ repeatedly to select **System** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ to select Clock or Phase item.
- 5 Press o or to adjust the value of the item until the screen is well-aligned.

Adjust the clock frequency of the set's internal clock signal. If shimmering or rainbow-like noise is apparent in the image, try adjusting the clock frequency setting.


You may find that images blur, depending on the clock phase of your PC's Processor. If you experience blurring, you can obtain a clearer image by adjusting the phase setting.


Adjusting the Picture Automatically


- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select System item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select Auto Adjust item.
- 5 Press OK to confirm.

The unit automatically adjusts phase, clock or position, etc.

The Auto Adjust function only works when the picture is displayed in 16:9 with full screen.







Setting System (continued)

Setting System In VGA Mode(continued)

Adjusting Screen Aspect

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **System** item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to highlight Aspect Ratio item.
- 5 Press **OK** repeatedly to select **4:3** or **16:9**.

Note:


You may quickly select the screen aspect by using the ASPECT button on the remote control.

Displaying Resolution Information

You may quickly display the resolution information by using the **Resolution** item.

Loading Default Values

You may quickly load default values by using the **Default** item.



Setting System In YPbPr Mode

Adjusting Phase

- Press **MENU** to display the menu main page.
- Press ▲ or ▼ repeatedly to select **System** item.
- Press **OK** to access the submenu. The Phase item will be highlighted automatically.
- 4 Press

 ✓ or

 ✓ repeatedly to adjust the value.



Adjusting Screen Aspect

- Press MENU to display the menu main page.
- Press ▲ or ▼ repeatedly to select **System** item.
- Press **OK** to access the submenu.
- Press ▲ or ▼ repeatedly to highlight Aspect Ratio item.
- Press **OK** repeatedly to select a desired aspect ratio.

For 480i or 480P signal format, you can select the image aspect ratio between 4:3, 16:9, Panorama and Zoom. For 720P or 1080i signal format, you can select the image aspect ratio between 4:3 and 16:9.

You may quickly select the screen aspect by using the ASPECT button on the remote control.

Reducing Picture Noise

- Press **MENU** to display the menu main page.
- Press ▲ or ▼ repeatedly to select **System** item.
- Press **OK** to access the submenu.
- Press ▲ or ▼ repeatedly to select N/R item.
- 5 Press OK repeatedly to select Off, Auto, Strong, Middle or Weak.

MAIN MENU & Picture Phase Sound Sound N/R 台CH ලදි System IEOSD TVPC Auto Setup

Loading Default Values

You may guickly load default values by using the **Default** item.



Aspect Ratio

Default

16:9

MAIN MENU

⊕ Picture

Sound Sound

ලදු System 置OSD

TVPC

○ Setup

台CH


Setting System (continued)

You must select DVI input source when you do the operations in DVI mode. As regards to the **connection**, **Sound** menu and **OSD** menu of DVI, refer to page 14 and page 28-29 of this manual. In DVI mode, **CH** menu displays grey and can't be selected.

Setting System In DVI Mode

Adjusting Screen Aspect

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select System item.
- 3 Press OK to access the submenu.
 The Aspect Ratio item will be highlighted automatically.
- 4 Press **OK** repeatedly to select **4:3** or **16:9**.



Note:


You may quickly select the screen aspect by using the ASPECT button on the remote control.

Displaying Resolution Information

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **System** item.
- 3 Press **OK** to access the submenu.

Customizing the Sound

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **Sound** item.
- 3 Press **OK** to access the submenu.
- 4 Press riangle or repeatedly to select the option items you want to adjust.
- 5 Press or to adjust the value or OK to toggle settings.



Option	Function	Operation	Range
Volume	Adjusts volume value.	 : stronger : weaker	0~100
Bass	Adjusts Bass (low sounds)	 : stronger : weaker	0~100
Treble	Adjusts Treble (high sounds).		0~100
Balance	Adjusts volume balance (left and right volumes).	►:Higher volume from right speaker.◄:Higher volume from left speaker.	
Mute	Mutes the sound	Use OK to toggle	On or Off
Speaker	Turns on or off speaker sound output	Use OK to toggle	On or Off
Head Phone	Turns on or off headphone sound output	Use OK to toggle	On or Off

Using the Preset Sound Mode


Use the **SOUND MODE** button to quickly select sound mode.

There are three preset sound modes (**Movie**, **Music** and **News**) and one user-set sound mode (**User**). Each preset mode has its own sound settings (Bass and Treble).

Movie: Select for a movie program. **Music**: Select for a music program.

News: Select for a speech or conversation program.

Adjusted settings are stored in **User** mode.



Setting SRS effect


Use the SRS button to quickly turn on or off the SRS effect.

SRS (Sound Retrieval System®) is an audio enhancement technology that restores the spatial cues that are present in a live listening environment and processes it to provide a natural 3D sound field.

* The SRS symbol is a trademark of SRS Labs, Inc. SRS technology is incorporated under license from SRS Labs, Inc.

Note:

When the SRS effect is set to On, the SRS function may affect the setting of Balance item.



Adjusting On-Screen Display

Adjusting OSD Position

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **OSD** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select H Position or V Position item.
- 5 Press or ▶ to adjust the OSD position.

Adjusting OSD Transparency

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **OSD** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select **Halftone** item.
- 5 Press or to adjust the OSD transparence.

Zooming OSD Menu

- 1 Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **OSD** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select **Zoom** item.
- 5 Press OK repeatedly to select Normal or Zoom.

Note:

When you zoom in the OSD menu, the V position item is unadjustable

Setting OSD Off Time


This setting allows you to set the time that the OSD for the main menu is displayed onscreen.


- 1 Press **MENU** to display the menu main page.
- Press ▲ or ▼ repeatedly to select OSD item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select **OSD Off** item.
- 5 Press **OK** repeatedly to select a proper time.


You may select between 5 seconds, 10 seconds, 20 seconds, 50 seconds or 200 seconds.


Loading default values

You may quickly load default values by using the Default item.










Viewing the TVPC


The **TVPC** function is available only when the main frame is in **VGA/DVI** mode and the aspect ratio is in 16:9 and the vertical frequency is 60 Hz.

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **TVPC** item.
- 3 Press OK to access the submenu.
 The TVPC On/Off item will be highlighted automatically.
- 4 Press **OK** to select **On** or **Off**.

Note:

- ▶ You may quickly open or close TVPC frame by using the **TV/PC** button directly.
- Audio is from the main picture only.





Selecting the Signal Source for the TVPC Frame

- 1 Press MENU to display the menu main page.
- Press ▲ or ▼ repeatedly to select **TVPC** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select **Source** item.
- 5 Press **OK** repeatedly to select signal source for the TVPC frame.

You may select RF, Video1, Video2, SVideo or YPbPr for the TVPC Frame.


Note:

You may quickly select signal source for the TVPC frame by using the **PIP INPUT** button.

Changing Channels for the TVPC Frame

When the TVPC frame is in TV mode, press the CH+ or CH- button to change channels.

When you press the **CH+** or **CH-**, the unit changes channels in sequence. You will see all the channels that the unit has memorized. You will not see channels that were erased.



TVPC Operations (continued)


Changing the Position of the TVPC Frame

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **TVPC** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select H Position or V Position item.
- 5 Press or ▶ to adjust the TVPC frame position.

MAIN MENU ⚠ Picture Source H Position V Position Size PBP TVPC Setup

Note:

You can quickly adjust TVPC position by using the ▲ ▼ ◆ ▶ button.



Adjusting the Size of TVPC Frame

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **TVPC** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select **Size** item.
- $\begin{tabular}{ll} 5 & Press & \textbf{OK} to adjust the TVPC frame size. \end{tabular}$

Note:

You may quickly adjust TVPC size by using the SIZE button.


Viewing Picture-by-Picture


You may view double windows by using PIP function.

- 1 Without TVPC function working, press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select TVPC item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select PBP item.
- 5 Press **OK** to turn on or off **PBP** function.

Note:


- You can quickly switch to PBP mode by using the **PIP** button.
- In PBP mode, the H Position and V Position item do not work if they are adjusted.






Setting Sleep Timer

Press the **SLEEP** button repeatedly to set a sleep time to automatically turn off the unit. Each press of the button changes the value:





Setting Audio Mode

Press the STEREO button repeatedly to select the audio mode between MONO, SAP and STEREO.

Choose STEREO for channels that are broadcasting in stereo.

Choose **MONO** for channels that are broadcasting in mono, or if you are having difficulty receiving a stereo signal.

Choose SAP to listen to the Second Audio Program, which is usually a foreign-language translation of a program.

To pause the Picture

Press the **PAUSE** • button to hold on the image on the screen (the video sources still run). Press again to reactivate the image.

Note:

The PAUSE function works in TV, Video or S-video mode only. For the sake of protecting the screen, please do NOT pause a picture for a long time.

Viewing Closed Captions

The unit decodes and displays the closed captions that are broadcast with certain TV shows. These captions are usually subtitles for the hearing impaired or foreign language translations. All VCRs record the closed caption signal from television programs, so home-recorded video tapes also provide closed captions. Most prerecorded commercial video tapes provide closed captions as well. Check for the closed caption symbol in your television schedule and on the tape's packaging:


Note:

The Caption feature does not work with YPbPr, VGA, DVI.

Not all the programs and videos will offer closed captioning. Please look for the 🚾 symbol to ensure that captions will be shown.

Turning Closed Caption On or Off

- 1 Press MENU to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **Setup** item.
- 3 Press OK to access the submenu.
 The CCD On/Off item will be highlighted automatically.
- 4 Press **OK** to select **On** or **Off**.



Setting Closed Caption

- Press **MENU** to display the menu main page.
- 2 Press ▲ or ▼ repeatedly to select **Setup** item.
- 3 Press **OK** to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select CCD mode item.
- 5 Press **OK** repeatedly to select a desired mode.

You may select between CC-1, CC-2, CC-3, CC-4, T-1, T-2, T-3 and T-4.

The Closed Caption broadcasts can be viewed in two modes: CAPTION and TEXT. For each mode, four channels are available.

The [CAPTION] mode shows subscripts of dialogues and commentaries of TV dramas and news programs while allowing a clear view of the picture.

The [TEXT] mode displays various information over the picture (such as TV program schedule, weather forecast, etc.) that is independent of the TV programs.


Note:


You may quickly select CCD mode by using the **CAPTION** button directly.

Setting CC When Mute

- Press **MENU** to display the menu main page.
- Press or repeatedly to select Setup item.
- 3 Press OK to access the submenu.
- 4 Press ▲ or ▼ repeatedly to select CC when mute item.
- 5 Press OK to select On or Off.

If you set this item to \mathbf{On} , the unit display closed caption when you mute the sound.





Child Lock

This function allows TV programs to be restricted and TV usage to be controlled based on FCC data. It prevents children from watching violent or sexual scenes that may be harmful.

Restriction of TV programs includes two ratings that contain information about the program: the MPAA rating and the TV Parental Guidelines. The MPAA rating is restricted by age. TV Parental Guidelines are restricted by age and content.

Since a TV program may use either the MPAA rating or the TV Guidelines, both should be adjusted for complete control.

[1] Movie Rating (MPAA)


Rating					
age based	G	GENERAL AUDIENCES. All ages admitted.			
	PG	PARENTAL GUIDANCE SUGGESTED. Some material may not be suitable for children.			
	PG-13	PARENTAL STRONGLY CAUTIONED. Some material may be inappropriate for children under 13.			
	R	RESTRICTED. Under 17 requires accompanying parent or adult guardian.			
	NC-17	NO ONE 17 AND UNDER ADMITTED.			
	X	X Rating is an older rating that is unified with NC-17 but may be encoded in the data of older movies.			
	N/A	NOT RATED.			

Note:

The Movie rating is only age-based.


Example 1:

"PG-13" in the age-based rating is blocked, this will automatically block the higher ratings "R", "NC-17", "X" also.




Example 2:

"R" in the age-based rating is blocked, this will automatically block the higher rating "NC-17", "X" also.



"Child Lock Block" with a green screen will be displayed if you watch the program with Program Rating data as same as you configured.



Adjusting Child Lock Settings (continued)

[2] TV Rating

Rating			4	content based		
		D	L	S	V	FV
age based	TV-Y (All children)	×	×	×	×	×
	TV-Y7 (Direct to Older Children)	×	×	×	×	•
	TV-G (General Audience)	×	×	×	×	
	TV-PG (Parental Guidance Suggested)	•	•	•	•	
	TV-14 (Parents Strongly Cautioned)	•	•	•	•	
	TV-MA (Mature Audience Only)		•	•	•	

Content Rating can be set but this Rating is not normally broadcast by TV Station.

----- Content Rating can be set.

D: Sexually Suggestive Dialog

L: Adult Language

S: Sexual Situation

V: Violence


FV: Fantasy Violence

Note:

Age-based ratings can be modified by the content-based ratings but only in the combinations indicated by an in the table above. Choosing lower age-based rating blocks the higher age-based ratings regardless of content ratings settings.

Example 1:


When TV-Y7 in the age-based rating is set to BLOCK, this will automatically block the higher ratings: TV-G, TV-PG, TV-14 and TV-MA. In addition, D, L, S, V and FV in content are automatically blocked.




Example 2:

When TV-14 in the age-based rating is set to BLOCK, this will automatically block the higher ratings: TV-MA

In addition, if you block "L" sub-rating in TV-PG, then the D, L, S, V and FV in content in TV-14 and TV-MA will automatically be blocked.



"Child Lock Block" with a green screen will be displayed if you watch the program with Program Rating data as same as you configured.



Turning Child Lock On or Off

- Press the **MENU** button to display the menu main page.;
- 2 Press ▲ or ▼ repeatedly to select Setup item;
- 3 Press OK to access the submenu;
- 4 Enter password with the **number buttons**.

The default password is 1234, you can change the password by yourself. The unit allows you to access the Child Lock menu if you input the right password, or you will be denied.

The Block On/Off item will be highlighted automatically.

5 Press **OK** to turn on or off the Child Lock.

Changing the Password

- 1 From the password menu page, press ▲ or ▼ repeatedly to select **New Password** item.
- 2 Input a new 4-digit password. For example, you may set "0000" as your new password.
- 3 Press the MENU button to exit.

Be sure to write down your password and retain it for future use.


The unit provides a master password "8888". If you forget your password and can't access Child Lock menu, you may input the master password to access Child Lock menu. Please set a new password and make sure to remember your password.


Adjusting the Movie Rating


- 1 From the Child Lock menu page, press ▲ or ▼ repeatedly to select MPAA item.
- Press OK repeatedly to select a desired rating you want to block.
 For example, "PG-13" in the age-based rating is selected, this will automatically block the higher ratings "R", "NC-17", "X" also.
- 3 Press the MENU button to exit.


Adjusting the TV Rating


- 1 From the Child Lock menu page, press ▲ or ▼ repeatedly to select TV Rating item.
- Press OK repeatedly to select a desired rating you want to block.
 This will automatically block the higher age-based ratings. You may set the individual content-based ratings as follow.
- 3 Press ◀ or ▶ if you want to set content-based ratings.
- 4 Press ▲ or ▼ repeatedly to select a desired content rating.
- 5 Press **OK** to block (\times) or unblock (\checkmark) this rating.
- 6 Press MENU repeatedly to exit.












Adjusting Child Lock Settings (continued)

Adjusting Canadian English Rating

- 1 From the Child Lock menu page, press ▲ or ▼ repeatedly to select CA EngRateSys item.
- Press **OK** repeatedly to select a desired rating you want to block.
- 3 Press the **MENU** button to exit.




CANADIAN ENGLISH RATING CHART

Е	Exempt - Exempt programming includes: news, sports, documentaries and other information programming, talk shows, music videos, and variety programming.	
С	Programming intended for children under age 8. No offensive language, nudity or sexual content.	
C8+	Programming generally considered acceptable for children 8 years and over. No profanity, nudity or sexual content.	
G	General programming, suitable for all audiences.	
PG	Parental Guidance suggested. Some material may not be suitable for children.	
14+	Programming contains themes or content which may not be suitable for viewers under the age of 14. Parents are strongly cautioned to exercise discretion in permitting viewing by pre-teens and early teens.	
18+	Intended for viewers 18 years and older and might contain depictions of violence.	

Adjusting Canadian French Rating

- 1 From the Child Lock menu page, press ▲ or ▼ repeatedly to select CA FrnRateSys item.
- 2 Press **OK** repeatedly to select a desired rating you want to block.
- 3 Press the MENU button to exit.



CANADIAN FRENCH RATING CHART

Е	Exempt - Exempt programming.
G	General - Programming intended for audience of all ages. Contains no violence, or the violence content is minimal or is depicted appropriately.
8 ANS+	8+ General - Not recommended for young children. Programming intended for a broad audience but contains light or occasional violence. Adult supervision recommended.
13 ANS+	Programming may not be suitable for children under the age of 13 - Contains either a few violent scenes or one or more sufficiently violent scenes to affect them. Adult supervisionstrongly suggested.
16 ANS+	Programming may not be suitable for children under the age of 16 - Contains frequent scenes of violence or intense violence.
18 ANS+	Only for adult viewing.Could contain frequent violent scenes and extreme violence.

Before calling for repair service, check the following items for possible remedies to the encountered symptoms.

Symptoms	Check item
"Ghost" or double images	This may be caused by obstruction to the antenna due to high rise buildings or hills. Using a highly directional antenna may improve the picture.
No power	Check that the AC power cord is plugged into the mains socket. Unplug the power cord, wait for 60 seconds. Then re-insert plug into the mains socket and turn on the unit again.
No picture	Check antenna connections at the rear of the unit to see if it is properly connected to the unit. Possible broadcast station trouble. Try another channel. Adjust the contrast and brightness settings. Check the Closed Captions control. Some TEXT modes could block the screen. Select a correct input. Is a non-compatible signal being input?
Good picture but no sound	Increase the VOLUME. Check that the unit is not muted. Check that the Speaker item in SOUND menu is set to ON.
Good sound but poor color	Adjust the contrast, color and brightness settings.
Poor picture	Sometimes, poor picture quality occurs when an activated S-VHS camera or camcorder is connected while another activated peripheral is connected. In this case, switch off one of the peripherals. Check whether the room is too bright.
Horizontal dotted line	This may be caused by electrical interference (e.g. hairdryer, nearby neon lights, etc.). Turn off the equipment.
Television not responding to remote control	Check whether the batteries are working. Replace if necessary. Clean the remote control sensor lens on the unit. Do not use the remote control under strong or fluorescent lighting. The batteries should be inserted with polarity (+, -) aligned.
Snowy picture and noise	Check the antenna connection.
Unstable or not synchronized VGA picture	Check if you have selected the correct VGA mode in your PC.
No output from one of the speakers	Adjust Balance in the SOUND menu.
Control buttons do not work.	Unplug the power cord, wait for 60 seconds. Then re-plug the power cord and turn on the unit again.

Do not use in hot and cold rooms (locations)

- When the unit is used in rooms (locations) with low temperature, the picture may leave trails or appear slightly delayed. This is not a malfunction, and the unit will recover when the temperature returns to normal.
- Do not leave the unit in a hot or cold location. Also, do not leave the unit in a location exposed to direct sunlight or near a heater, as this may cause the cabinet to deform and the LCD panel to malfunction.

(Storage temperature: 0°C to +50°C; Working temperature: 5°C to +40°C)

Note:

Care and Maintenance

LCD Display panel information

Important Information Regarding Use of Video Games, Computers, Captions or Other Fixed Image Displays.

The extended use of fixed image program material can cause a permanent "shadow image" on the LCD panel.

This background image is viewable on normal programs in the form of a stationary fixed image. This type of irreversible LCD panel deterioration can be limited by observing the following steps:

- A. Reduce the brightness/contrast setting to a minimum viewing level.
- B. Do not display the fixed image for extended periods of time.
- C. Turn the power off when not in actual use.

Note:

The marking or retained image on the LCD panel resulting from fixed image use is not an operating defect and as such is not covered by Warranty. This product is not designed to display fixed image patterns for extended periods of time.

Cleaning and Maintenance

To clean this unit, wipe with a soft, dry cloth.

If the surfaces are extremely dirty, use a soft cloth dipped in a soap and water solution or a weak detergent solution.

- Use eyeglass cleaner to remove stubborn dirt from the LCD.
- Never use alcohol, paint thinner or benzine to clean this unit.
- Before using a chemically treated cloth, read the instructions that came with the cloth carefully.

Type LCDTV Display Size diagonal 32"

Display Feature

LCD panel TFT-LCD
Resolution 1366 x 768

Pixel Pitch 0.1730 (H)x 0.5190(V) mm

Maximum Colors16,700,000Brightness550 nitContrast800:1Viewing Angle170°/170°

Response Time 16.6 ms (Gray to gray Typ.)

TV Tuner & Color System

Tuner FST x 1 TV System NTSC

Channel Coverage VHF 2-13, UHF 14-69, CATV (1-125)

Video Features Progressive Scan

Audio Speaker System

Maximum Audio Output 7Wx2 Stereo Sound System BTSC

Power Supply AC 100V-240V 50/60Hz

Power Consumption 200W
Stand by Mode Power Consumption <1W
Unit weight (lb) 46

TV Unit Dimension (WxHxD) (inch) 36.9 x 22.15 x 8.66
Other functions Sleep Timer (Off only)

Picture Freeze (TV and AV only)

Caption Closed Caption Security Child Lock

Remote Control function support for OSD Support English, French, Spanish

full OSD features

Specification (continued)

Terminals

Video In RF: TV/CATV 75ohms coaxial x 1

AV: RCA75ohms composite video x 2

S-Video: 4-pin DIN x 1

D-Sub 15 x 1 DVI-Dx1

YPbPr (Support HDTV): RCA for DVD, STB x 1

Video Out RCA75 ohms x1
Audio In L/R RCA for AVx2

Stereo mini phone Jack for PC x 1 Stereo mini phone Jack for DVI-D x 1

L/R RCA for YPbPr x1

Audio Out L/R RCA for Video Out x 1

Headphone Jack: Stereo mini phone Jack x 1

Standard Accessories 1 User Manual

1 Remote Control 1 Power Cord

Optional Accessories 2 AAA Batteries

1 VGA Cable 1 S-Video Cable

1 Component-Video Cable (YPbPr/YCbCr),

1 Audio/Video Cable 1 Audio Cable (RCA)

1 Audio Cable (RCA to Stereo mini phone Jack)

Display Format Supported by This Unit

For VGA/DVI: 640X480 @ 60Hz,72Hz,75Hz,85Hz; 800X600 @ 60Hz,72Hz,75Hz,85Hz;

1024X768 @ 60Hz,75Hz,85Hz; 1280X960 @ 60Hz;

1280X1024@60Hz.

For YPbPr: 480P @ 60Hz; 480i @ 60Hz;

720P @ 60Hz; 1080i @ 60Hz.

Programming the Polaroid Universal Remote Control

Following are two sets of instructions for programming your Polaroid Universal Remote Control to work with other devices in addition to your Polaroid TV. (If you only wish to use the remote control with your Polaroid TV, no additional programming is necessary.) Begin with the Direct Programming Setup, and if unsuccessful, go on to the Auto Code Search Setup.

Direct Programming Setup

This method requires use of one of the device codes found in the Device Code Table (see last pages of your Operating Manual). Begin with the first code listed for your device.

- 1 Turn the device power off and <u>point</u> the Polaroid Universal Remote Control at the device you wish to control.
- 2 Momentarily press a device button on the Polaroid Universal Remote Control (**TV**, **DVD**, **CBL**, or **AUX**). When you release the device button the red LED at the top of the remote will blink once.

Note: For devices other than a TV, DVD, or Cable Box, use the **AUX** key.

- 3 Press and <u>hold</u> the **SET** button (top-left button) until you see the LED blink once, followed by two short blinks. Release the **SET** button after you see the two short LED blinks.
- 4 Enter the 5-digit code from the code table for the device you want to control. The LED blinks once each time you press a numbered button. **After you enter the last digit**:
 - a) If the code you entered is the correct code for your device, you will see the LED blink twice. Go to step 5.
 - b) If the code you entered is <u>not</u> the correct code for your device, you will see the LED blink **once**. Repeat steps 2-4, this time choosing the next code in the list.
- 5 Press the Power button (top right-side button) on the remote and your device power should turn on. If the power does not turn on, repeat the entire procedure beginning with step 1.

If you are unable to program the remote properly after two or more attempts using the Direct Programming Setup, go on to the Auto Code Search Setup.

Auto Code Search Setup

This method does not require use of the Device Code Table.

- 1 Turn the device power off and <u>point</u> the Polaroid Universal Remote Control at the device you wish to control.
- 2 Momentarily press a device button on the Polaroid Remote Control (**TV**, **DVD**, **CBL**, or **AUX**). When you release the device button the red LED at the top of the remote will blink once.

Note: For devices other than a TV, DVD, or Cable Box, use the AUX key.

- 3 Press and <u>hold</u> the **SET** button (top-left button) until you see the LED blink once, followed by two short blinks. Release the **SET** button after you see the two short LED blinks.
- 4 Press **9 9 1** on the number pad. Each time you press the number **9** button the LED blinks **once**. When you press the number **1** button, the LED blinks **twice**.
- 5 Enter the following number, depending on the device you are trying to control. When you release the button, you should see two short LED blinks.

Cable or Satellite box – Press 0
TV – Press 1
DVD player – Press 2
Audio device or VCR – Press 3

- 6 Momentarily press the power button (top-right button) and release it.
- 7 Press the CH+ button, slowly and repeatedly, until the device you want to control turns on. Stop pressing immediately when the device power turns on.

Note: If you press the **CH+** button too quickly you may save the wrong code, in which case the remote control will not turn the device power on. Start at step 1 and repeat the programming steps again.

8 When the device turns on, press and <u>hold</u> the **SET** button until you see the LED blink **twice**. The code is now saved, and the remote should operate properly.

Remote Control ID Code List

Setup Code For TVs

 Addison
 10092

 Admiral
 10093, 10463

 Advent
 10761, 10842

 Aiko
 10092

Aiwa 11914

Akai 10812, 10702, 10030, 10672, 11903

Albatron 10700, 10843

America Action 10180

Anam National 10250, 10180, 10700 10250, 10650

Anhua 10051

AOC 10451, 10093, 10180, 10060, 10030, 10178, 10092

Apex Digital 10748, 10765, 10879, 10767, 11943 Audiovox 10451, 10180, 10875, 10092, 10623

 Baile
 10661

 Beijing
 10812, 10661

 Bell & Howell
 10154

 BenQ
 11032

 Bradford
 10180

Broksonic 10236, 10463, 11911, 11938, 11905, 11935, 11929

 Cailing
 10748

 Candle
 10030

 Carnivale
 10030

 Carver
 10054

 Celebrity
 10000

 Celera
 10765

 Changebong
 10051

Changcheng 10051, 10661

Changhong 10156, 10765, 11156, 10767

Ching Tai 10092

Chun Yun 10000, 10180, 10700, 10092, 10843

Chung Hsin 10180, 10053

Cinema 10672

Citizen 10060, 10030, 11928, 10092

Clarion 10180

Commercial Solutions 11447, 10047

Conrowa 10156, 10145, 11156

 Contec
 10180

 Craig
 10180

 Crosley
 10054

 Crown
 10180

Curtis Mathes 10047, 10054, 10154, 10451, 10093, 10060, 10702, 10030, 10145, 10166

CXC 10180

Daewoo 10154, 10451, 10180, 10030, 10178, 10672, 11928, 10092, 10661, 11909,

10623, 10700

 Dayu
 10661

 Dell
 11080

 Denon
 10145

 Dumont
 10017

Durabrand 10463, 10180, 10178, 10171, 11034

Electroband 10000

Emerson 10154, 10236, 10463, 10180, 10178, 10171, 11944, 11909, 11929, 11905, 11928,

10623, 11911

Envision 10030 Ether 10030

 Firstar
 10236

 Fisher
 10154

 Fortress
 10093

Fujitsu 10809, 10853

Funai 10180, 10171, 11904

Furi 10145 Futuretech 10180

Gateway 11756, 11755

GE 11447, 10047, 11454, 10051, 10451, 10180, 10030, 10178, 11917, 10092, 11907,

11922

Gibralter 10017, 10030

GoldStar 10154, 10030, 10178, 11926

Grunpy 10180

Haier 11034 Hallmark 10178

Hankook 10180, 10030, 10178

Harley Davidson 11904 Harman/Kardon 10054 Harvard 10180 Havermy 10093 Helios 10865 Hello Kitty 10451

Hisense 10156, 10748, 10145, 11156

Hitachi 10156, 10030, 10178, 11145, 10145, 10092, 11904, 11156

 Hongmei
 10093

 Huafa
 10145

 Huari
 10145

 Huodateji
 10051

Imperial Crown10661Infinity10054Inteq10017

JBL 10054 JCB 10000

Jean 10156, 10051, 10236, 10092

 Jensen
 10761

 Jiahua
 10051

 Jinfeng
 10051

Jinxing 10054, 10156, 10145 JVC 10053, 11923, 11253

 Kangli
 10661

 KEC
 10180

 Kenwood
 10030

KLH 10765, 10767

Kolin 10180, 10150, 10053 KTV 10180, 10030 Kunlun 10051, 10661

LG 10060, 10030, 10178, 10856, 10700, 10025

Lloyd's 11904

LXI 10047, 10054, 10154, 10156, 10178

Magnasonic 11928, 11913

Magnavox 11454, 10054, 10030, 10706, 11931, 11254, 11913, 11904, 11944

Magnin 11907

Marantz 10054, 10030, 10704

Matsushita 10250, 10650

Maxent 11755 Megapower 10700

Megatron 10178, 10145

Memorex 10154, 10463, 10150, 10178, 11911, 11926, 11924, 11920, 11927

MGA 10150, 10030, 10178, 11907

Midland 10047, 10017, 10051

Mitsubishi 10154, 10250, 10093, 10236, 10180, 11250, 10150, 10030, 10178, 11917, 10836

Monivision 10843, 10700

Motorola 10093

MTC 10060, 10030

Mudan 10051 Multitech 10180

NAD 10156, 10178, 10866

National 10051

NEC 10154, 10156, 10051, 10053, 10030, 10178, 11704

Newave 10093, 10178, 10092 Nikko 10030, 10178, 10092

Norcent 10748, 10824

NTC 10092

Onwa 10180

Optimus 10154, 10250, 10166, 10650, 11927, 11924, 11913

Optonica 10093

Orion 10236, 10463, 11929, 11911, 11905

Panasonic 10054, 10250, 10051, 10650, 11941, 11927, 11924

Panda 10051, 10706

Penney 10047, 10156, 10051, 10060, 10030, 10178, 11926, 11907

Philco 10054, 10180, 10030, 10178

Philips 11454, 10054, 10000, 10051, 10030, 10178, 10092, 10690

Pilot 10030

Pioneer 10166, 10866, 10679

 Portland
 10092

 Prima
 10761

 Princeton
 10700

 Prism
 10051

Proscan 11447, 10047, 11922

Proton 10030, 10178

Pulsar 10017

Qingdao 10051

Quasar 10250, 10051, 11924, 10650

RadioShack 10047, 10154, 10180, 10030, 10178, 11920, 11904

RCA 11447, 10047, 11454, 10000, 10030, 10178, 11547, 11922, 1917, 10092, 11907,

11948, 10090, 10679

Realistic 10154, 10180, 10030, 10178

Rowa 10748

Runco 10017, 10030

Sampo 10154, 10093, 10030, 10178, 10171, 10700, 10650, 11755, 10092

Samsung 10154, 10156, 10060, 10812, 10702, 10030, 10178, 11060, 10814, 10092,

11903, 10090, 10766

Sansui 10463, 11904, 11935, 11929, 11911 Sanyo 10154, 10156, 10180, 10145, 11907

Sanyuan 10093 Scotch 10178

Scott 10236, 10180, 10178

Sears 10047, 10054, 10154, 10156, 10178, 10171, 11926, 11904

Shaofeng 10145

Sharp 10093, 10030, 10650, 11917

 Shen Ying
 10092

 Shencai
 10145

 Sheng Chia
 10093, 10236

 Skygiant
 10180

 Skyworth
 10748

Sony 11100, 10000, 10650, 11925, 11904

Soundesign 10180, 10178

Sowa 10156, 10051, 10060, 10178, 10092

 Squareview
 10171

 SSS
 10180

 Starlite
 10180

 Studio Experience
 10843

 Supreme
 10000

 SVA
 10748

SVA 10748, 10865

Sylvania 10054, 10030, 10171, 11944, 11931 Symphonic 10180, 10171, 11913, 11904

Synco 10000, 10451, 10093, 10060, 10178, 10092

Tacico 10178, 10092

Tandy 10093

Tashiko 10092, 10650

Tatung 10054, 10154, 10156, 10051, 10060, 11156, 11756, 11254

Technics 10250, 10051

Techwood 10051

Teco 10051, 10093, 10178, 10092

Teknika 10054, 10180, 10150, 10060, 10092

 Telefunken
 10702

 Tera
 10030

 Thomas
 11904

 Tiane
 10093

 TMK
 10178

 TNCi
 10017

 Tobo
 10748

Toshiba 10154, 10156, 10060, 10145, 11945, 11704, 11936, 11156, 11935, 10650, 11918

Tuntex 10030, 10092

TVS 10463

V Inc. 11756, 10885, 10864

Vector Research 10030

Victor 10250, 10053, 10650

Vidikron 10054 Vidtech 10178

Viewsonic 11755, 10885, 10864

Wards 10054, 10030, 10178, 10866, 11156

Warumaia 10661 Waycon 10156

White Westinghouse 10463, 11909, 10623

Yamaha 10030 Yapshe 10250

Zenith 10017, 10463, 10178, 11904, 11929, 11911, 11909, 10092

Setup Code For VCRs

ABS 21972

Admiral 20048, 20209

Aiko 20278

Aiwa 20037, 20479

Alienware 21972 America Action 20278 American High 20035 Amoisonic 20479

Anam 20162, 20037, 20240, 20278

Anam National 20162 Asha 20240

Audiovox 20037, 20278

Beaumark 20240 Bell & Howell 20104

Broksonic 20184, 20121, 20209, 20002, 20479

 Calix
 20037

 Canon
 20035

 Carver
 20081

 CCE
 20072, 20278

 Changhong
 20048, 20081

 Citizen
 20037, 20278

Colt 20072

Craig 20037, 20047, 20240, 20072

Curtis Mathes 20060, 20035, 20162

Cybernex 20240 CyberPower 21972

Daewoo 20045, 20104, 20278

Dell 21972 Denon 20042

DirecTV 20039, 20038

Electrohome 20037 Electrophonic 20037 Emerex 20032

Emerson 20035, 20037, 20184, 20240, 20045, 20121, 20043, 20209, 20002, 20278, 20479

Fisher 20047, 20104 Fuji 20035, 20033

Fujitsu 20045

Gateway 21972

GE 20060, 20035, 20240

General 20045 Go Video 20432

GoldStar 20037, 20209, 20038, 20225

 Haojie
 20240

 Harman/Kardon
 20081, 20038

 Harwood
 20072

 Hewlett Packard
 21972

 HI-Q
 20047

Hitachi 20037, 20042, 20055

Howard Computers 21972 HP 21972

Hughes Network Systems 20042, 20739

iBUYPOWER 21972

JVC 20045, 20067 KEC 20037, 20278

Kenwood 20067, 20038

KLH 20072 Kodak 20035, 20037

Kolin 20043

LG 20037, 20045, 20042, 20209, 20038

Logik 20072 LXI 20037

Magnavox 20035, 20039, 20081

Magnin 20240

 Marantz
 20035, 20081

 Marta
 20037

 Matsushita
 20035, 20162

Media Center PC 21972 MEI 20035

Memorex 20035, 20162, 20037, 20048, 20039, 20047, 20240, 20104, 20209, 20479

MGA 20240, 20043

MGN Technology20240Microsoft21972Mind21972Minolta20042

Mitsubishi 20067, 20043 Motorola 20035, 20048

MTC 20240 Multitech 20072

NEC 20035, 20037, 20048, 20104, 20067, 20038

 Newave
 20037

 Nikko
 20037

 Noblex
 20240

 Northgate
 21972

Olympus 20035

Optimus 21062, 20162, 20037, 20048, 20104, 20432

Orion 20184, 20209, 20002, 20479

Panasonic 21062, 20035, 20162, 20616, 20225 Penney 20035, 20037, 20240, 20042, 20038

Pentax 20042

Philco 20035, 20479

Philips 20035, 20081, 20739, 20618

Pilot 20037

 Pioneer
 20042, 20067

 Polk Audio
 20081

 Profitronic
 20240

 Proscan
 20060

 Protec
 20072

 Pulsar
 20039

Qisheng 20060

Quasar 20035, 20162

Radix 20037 Randex 20037

RCA 20060, 20035, 20240, 20042, 20880 Realistic 20035, 20037, 20048, 20047, 20104

ReplayTV 20616 Runco 20039

Sampo 20037, 20048

Samsung 20240, 20045, 20432

Sanky 20048, 20039

Sansui 20067, 20209, 20479 Sanyo 20047, 20240, 20104 Scott 20184, 20045, 20121, 20043

Sears 20035, 20037, 20047, 20042, 20104

Sharp 20048, 20209

 Shintom
 20072

 Shogun
 20240

 Singer
 20072

 Sonic Blue
 20616

Sony 20035, 20032, 20033, 20636, 21972

STS 20042

Sylvania 20035, 20081, 20043

Systemax 21972

Tagar Systems 21972 Tashiko 20037

Tatung 20045, 20067 Technics 20035, 20162

Teco 20035, 20037, 20048, 20038

Teknika 20035, 20037

Tivo 20636, 20618, 21503, 20739

TMK 20240

Toshiba 20045, 20042, 20067, 20043, 21503, 21008, 21972

Totevision 20037, 20240

Touch 21972

Unitech 20240

 Vector
 20045

 Vector Research
 20038

 Victor
 20067

 Video Concepts
 20045

 Videomagic
 20037

 Videosonic
 20240

 Viewsonic
 21972

Wards 20060, 20035, 20048, 20047, 20081, 20240, 20042, 20072

White Westinghouse 20209, 20072

XR-1000 20035, 20072

Yamaha 20038

Zenith 20039, 20033, 20209, 20479

ZT Group 21972

Setup Code For Digital Video Disks

Aiwa 20641, 21912

Akai 20770 Allegro 20869

Apex Digital 20672, 20717, 20797, 21061, 20796, 21056, 21937, 20794, 21020, 21915

Blaupunkt 20717 Blue Parade 20571 Broksonic 20695

 Changhong
 20627, 21061

 CineVision
 20869

 Coby
 21086

 Curtis Mathes
 21087

CyberHome 21024, 21023, 21129, 20816, 21117

Daewoo 20833, 21172, 20869

Denon 20490 DVD2000 20521

Emerson 20591, 20675

Enterprise 20591

Fisher 21919 Funai 20675

Gateway 21158, 21073 GE 20522, 20717

Go Video 20744, 20833, 21099, 20783, 21075, 20869, 21730

Greenhill 20717

Harman/Kardon 20582, 20702

Hitachi 20573, 20664, 21919

Hiteker 20672

Initial 20717

Integra 20627, 21924

JBL 20702

JVC 20558, 20623, 20867

Kenwood 20490, 20534

KLH 20717, 21020, 21149

Koss 20651, 21980

Lasonic 20798

LG 20591, 20869, 20801

Liquid Video 21980 Lite-On 21158, 21058

Loewe 20511

Magnavox 20503, 20539, 21976, 21914, 20675

 Marantz
 20539

 Memorex
 20695

 Microsoft
 20522

 Mintek
 20717

Mitsubishi 21521, 20521

 Nesa
 20717

 Norcent
 21003

Onkyo 20503, 20627, 21924, 20792

Oritron 20651, 21980

Panasonic 20490, 21762, 21990

Philips 20503, 20539, 20646, 21914

Pioneer 20525, 20571 Polaroid 21086, 21061

Polk Audio20539Portland20770Proscan20522

Qwestar 20651

RCA 20522, 20571, 20717, 20822

Rio 20869 Rotel 20623

Sampo 20752, 20698

Samsung 20490, 20573, 21932, 21075, 20820

 Sansui
 20695

 Sanyo
 20695

Sharp 20630, 20752

 Sharper Image
 21117

 Sherwood
 20770

 Shinco
 20717

 Shinsonic
 20533

Sonic Blue 20869, 21099

Sony 20533, 20864, 21033, 21904, 21903

 SVA
 20717

 Sylvania
 20675

 Symphonic
 20675

20717, 21984, 20809 Teac

Technics 20490 Theta Digital 20571

Toshiba 20503, 20695

20503 **Urban Concepts**

20522 Xbox

Yamaha 20490, 20539, 20545

20503, 20591, 20869 Zenith

Setup Code For Cable Converters

ABC 00003, 00008, 00014

Americast 00899

Bell & Howell 00014 Bell South 00899

Clearmaster 00883 ClearMax 00883 Coolmax 00883

01877, 00877, 00477, 00008 Daeryung

Digi 00637 Director 00476 **Dumont** 00637

Gehua 00476

General Instrument 00476, 00810, 00276, 00003, 00014

GoldStar 00144

Hamlin 00009, 00273

Hitachi 00014

00476, 00810, 00276, 00003, 00012, 00014 Jerrold

KNC 80000

LG 00144

00000 Memorex

00476, 00810, 00276, 01254, 01376 Motorola

MultiVision 00012

Pace 01877, 00237 00000, 00008, 00107 Panasonic

00637 Panther 00000

Paragon **Philips** 00317, 01305

01877, 00877, 00144, 00533 Pioneer

00000 Pulsar

00000 Quasar

RadioShack 00883

Regal 00279, 00273

Runco 00000

00000, 00144 Samsung

Scientific Atlanta 01877, 00877, 00477, 00008

Sony 01006

Starcom 00003, 00014

Supercable 00276 Supermax 00883
 Tocom
 00012

 Torx
 00003

 Toshiba
 00000

 Trans PX
 00276

 Tristar
 00883

 TS
 00003

 V2
 00883

 Viewmaster
 00883

 Vision
 00883

 Vortex View
 00883

Zenith 00000, 00525, 00899

Setup Code For Satellite Receivers

AlphaStar 00772

Chaparral 00216 Crossdigital 01109

DirecTV 00392, 00566, 00639, 01142, 00247, 00749, 01749, 00724, 00819, 01856, 01076,

01109, 00099, 01392, 01640, 01442, 01414, 01108

Dish Network System 01005, 00775, 01505 Dishpro 01005, 00775, 01505

Echostar 01005, 00775, 01505

Expressvu 00775

 GE
 00566

 General Instrument
 00869

 GOI
 00775

 Goodmans
 01246

Hisense 01535

Hitachi 00819, 00222, 01250

HTS 00775

Hughes Network Systems 01142, 00749, 01749, 01442

I-Lo 01535 JVC 00775

LG 01414, 01226

Magnavox 00724, 00722

Memorex00724Mitsubishi00749Motorola00869

NEC 01270 Next Level 00869

Panasonic 00247, 00701

Paysat 00724

Philips 01142, 00749, 01749, 00724, 01076, 00722, 00099, 01442

Proscan 00392, 00566

Proton 01535

RadioShack 00869

RCA 00392, 00566, 00855, 00143, 01392

Samsung 01276, 01109, 01108

Sanyo 01219 SKY 00856

Sony 00639, 01640

Star Choice 00869

Tivo 01142, 01442

Toshiba 00749, 01749, 00790, 01285

UltimateTV 01640, 01392 Uniden 00724, 00722

US Digital 01535 USDTV 01535

Voom 00869

Zenith 00856, 01856

Setup Code For Audio Amplifiers

Bose 30674 GE 30078 JVC 30331 Marantz 30321 Nakamichi 30321 **NEC** 30264 **Optimus** 30395 Realistic 30395 Sansui 30321 Shure 30264 Sony 30689 Soundesign 30078 Victor 30331 Wards 30078

Yamaha 30354, 30133

Setup Code For CD Players

Aiwa 30157

Burmester 30420

California Audio Labs 30029

Carver 30157, 30179

 Denon
 30873

 DKK
 30000

 DMX Electronics
 30157

 Dynamic Bass
 30179

Fisher 30179

 Garrard
 30420

 Genexxa
 30032

Harman/Kardon 30157, 30173

Hitachi 30032

Integra 30101

JVC 30072

Kenwood 30826, 30626, 30028, 30037, 30036, 30190

Krell 30157

Linn 30157

Magnavox 30157

Marantz 30626, 30029, 30157

MCS 30029 Miro 30000
 Mission
 30157

 MTC
 30420

NSM 30157

Onkyo 30868, 30101

Optimus 31063, 30000, 30032, 30037, 30420, 30179, 31075, 30145

Panasonic 30029 Parasound 30420

Philips 30626, 30157

Pioneer 31063, 31062, 30032

Polk Audio 30157 Proton 30157

 QED
 30157

 Quad
 30157

 Quasar
 30029

RadioShack 31075

RCA 31062, 30032, 30420, 30179, 30053

Realistic 30420, 30179 Rotel 30157, 30420

 SAE
 30157

 Sansui
 30157

 Sanyo
 30179

 SAST
 30157

 Sharp
 30861, 30037

 Silsonic
 30888, 30036

Sonic Frontiers 30157

Sony 30490, 30000, 30100

Soundesign 30145

 TAG McLaren
 30157

 Tascam
 30420

 Teac
 30420

 Technics
 30029

Victor 30072

Wards 30157, 30053

Yamaha 30888, 30036

Zonda 30157

Setup Code For Audio Amp/Tuners

ADC 30531

Aiwa 31405, 31243, 30121

Anam 31609, 31074

Audiotronic 31189

Bose 31229

 Capetronic
 30531

 Carver
 31189

 Coby
 31263

Denon 31360, 31142, 30904

Fonmix 31360

Glory Horse 31263

Harman/Kardon 30110 Hitachi 31273

 Inkel
 30027

 Integra
 30135

JBL 30110

JVC 30074, 31263

Kenwood 31313, 31570, 30027

KLH 31428

 Magnavox
 31189, 31269, 30531

 Marantz
 31189, 31269, 30039

MCS 30039

Onkyo 30842, 30135

Optimus 31023, 30670, 30531, 31074

Panasonic 31518, 30039 Philips 31189, 31269

Pioneer 31023, 30150, 30014, 30630, 30531

Proscan 31254

Qisheng 31609 Quasar 30039

RadioShack 31263

RCA 31023, 31609, 31254, 30531, 31074

Sharper Image 31263 Silsonic 30176

Sony 31058, 31441, 31258, 31759

Soundesign 30670 Stereophonics 31023 Sunfire 31313

Teac 31074, 31267

Technics 31308, 31518, 30039

Thorens 31189

Victor 30074

Wards 30014

Yamaha 30176, 31276, 31176

For service, support and warranty information, visit $\underline{www.pwwservice.com}$ or call 1-866-396-6322.

"Polaroid" is a registered trademark of Polaroid Corporation of Waltham, MA USA and licensed for use on the FLM-3201 to Petters Consumer Brands, LLC.

